

3.6M BOARD

NORDECK WOODGRAIN EFFECT DECKING



Cladco Nordeck Woodgrain Effect
Decking Boards are made with
extremely resilient materials,
providing resistance against fading,
staining or scratching. Nordeck
Decking Boards feature a luxurious
texture replicating natural wood, and
come in six contemporary colours.
Nordeck Decking Boards benefit
from a 20-year structural warranty
and are composed of a solid PVC
core encased in an ASA-resin shell for
superior strength and durability.


*When installed with Cladco Recycled Plastic Joists.

COLOUR RANGE





BOARD SPECIFICATIONS	
Length	3.6m
Width	200mm
Thickness	32mm
Coverage	0.7m ²
Weight	18.2kg











PVC-ASA MATERIAL

Cladco Nordeck Woodgrain Effect Decking is composed of a dense PVC core encased in an ASA resin, providing superior resilience against weather, scratching, UV fading and rot damage.

The tough PVC-ASA Capstock material is suitable for use low to the ground or in damp areas, such as around pools or hot tubs, due to its moisture resistant properties.

Nordeck Woodgrain Effect Decking is highly resistant to general wear and tear, and also resists stains or scratches. Nordeck Woodgrain Effect Decking has a remarkable natural wood effect look and feel due to its embossed surface. This type of decking is extremely UV resistant and maintains its original colour after sun exposure.

AFTERCARE

Cladco Nordeck Woodgrain Effect Decking is low maintenance and easy to clean with soapy water when needed. Pressure washers can be used occasionally, keeping a distance of 250mm-300mm away from the surface. By following these methods, your Nordeck Decking Boards will look exceptional for years to come.



INSTALLATION ADVICE

Prepare your Base

Choose to lay Nordeck Decking over a concrete base or a grass/soil base. The concrete base should have a slight slope of around 5mm for drainage. The grass/soil base should be even and debris free. Lay Cladco Weed Mat and cover with stones or chippings.



Framework

Prepare a framework for your Decking using joists cut to your required length. To create a raised frame you will need to add blocks of timber.

Allow a slight angle of 5mm for every metre to enable drainage. Set joists every 300mm and screw them into place from the outside of your frame, adding extra support with legs.



Lay your Decking

Lay out your Decking onto the desired space, ensuring a 3mm gap between Boards and obstructions. Secure the end Board to the frame with Hidden Deck Fasteners or SPEEDDEKZ Decking Screws. After installing all Boards ensure they are lined up. Follow with Nordeck Bullnose Boards and Fascia Boards, if required.



For detailed information about installation, please read our Nordeck Woodgrain Effect Installation Guide.

PRODUCT ACCESSORIES



BULLNOSE BOARDS



COMPOSITE JOISTS



SPEEDDEKZ 316 STAINLESS STEEL SCREWS



FASCIA BOARDS



TIMBER JOISTS



MAGNETIC PHILLIPS IMPACT SCREWDRIVER BITS



CTI ADHESIVE



WEED MAT & PINS BUNDLE



65MM HIDDEN DECK FASTENERS

